



Bike Training Handle Instructions

WARNING:

Read these instructions completely BEFORE beginning installation of this product. If you lack the knowledge or tools to perform the installation, please have your local professional bicycle mechanic perform the installation. Improper installation can result in loss of control or damage to the bicycle and/or serious injury or death to the rider. We STRONGLY recommend installation of this product be performed by a professional bicycle mechanic.

INSTRUCTIONS

Step 1.

Partial disassembly of the clamp is required in order to fit the clamp of the handle around the seatpost of the bicycle. To disassemble, use the lever to unscrew the lever and nut assembly from the bolt and loosen the nutted bolt on the other side of the clamp, but do not fully remove.

Step 2.

Using a 13mm box end wrench, set clamp tension on nutted side of clamp, making sure the gap on each side of the clamp is equal.

Step 3.

Tighten the other side of the clamp using the lever. The clamp should be tight on the seatpost, but some movement is acceptable

Step 4.

Tighten the nutted side of the clamp to 35–45 in lb using a 13mm wrench.

LIMITED 2-YEAR WARRANTY:

DIMENSION® guarantees its products against manufacturer defects in materials and workmanship for a period of two (2) years from the original date of purchase, subject to the limitations below. The proof of purchase date is the one that is specified on the retail sales receipt issued by the authorized DIMENSION dealer.

TO THE EXTENT NOT PROHIBITED BY LAW, THIS WARRANTY IS EXCLUSIVE AND THERE ARE NO OTHER EXPRESS OR IMPLIED WARRANTIES OR CONDITIONS INCLUDING WARRANTIES OR CONDITIONS OF MERCHANTABILITY AND FITNESS FOR A PARTICULAR PURPOSE.

This warranty does not cover the following:

- Damage due to improper assembly or follow-up maintenance or lack of skill, competence or experience of the user or assembler
- Products that have been modified, neglected, used in competition or for commercial purposes, misused or abused, involved in accidents or anything other than normal use
- Damage or deterioration to the surface finish, aesthetics or appearance of the product
- Normal wear and tear
- Labor required to remove and/or refit and re-adjust the product within the bicycle assembly
- Installation of components, parts, or accessories not originally intended for or compatible with DIMENSION products as sold

This limited warranty is expressly limited to the repair or replacement of a defective product, at the option of DIMENSION, and is the sole remedy of the warranty. This limited warranty applies only to the original purchaser of the DIMENSION product and is not transferable. This warranty applies only to DIMENSION products purchased through an authorized dealer or distributor. In no event shall DIMENSION be liable for any loss, inconvenience or damage, whether direct, incidental, consequential, or otherwise resulting from breach of any express or implied warranty or condition, of merchantability, fitness for a particular purpose, or otherwise with respect to DIMENSION products except as set forth herein. This warranty gives the consumer specific legal rights, and those rights and other rights may vary from place to place. This warranty does not affect your statutory rights.

Contact Us:
DIMENSION®
6400 W. 105th St.
Bloomington, MN 55438
855.883.6563
dimensionbikeproducts.com